



IceSLEET® X7 Dual

Quick Start Guide

Iceberg-Thermal.com

Box Content

A



x1

B




x4

C




x1

D




x1

E



x1

F



x1

AMD

G




x4

H



x4

I



x2


INTEL

J



x4

K




x2

L



x4

M



x1


AMD

AM4


B



I



G




AM3(+) / AM2(+) / FM2(+) / FM1


B



I




H




AMD


AM4



AM3(+) / AM2(+) FM2(+) / FM1



AMD




INTEL

LGA 2066 / 2011-0 / 2011-3 (Square ILM)


B



K



J




LGA 1200 / 115X / 1366 / 775

B




K



L




M




INTEL

K




M




INTEL

LGA 2066 / 2011-0 / 2011-3 (Square ILM)




INTEL

LGA 1200 / 115X / 1366 / 775




INTEL


LGA 1200 / 115X / 1366 / 775




Step 1




Step 2




Step 3




Step 4




Step 5




Step 6




Step 7



Step 8



Step 9



Step 10

